



**wieland**

www.wieland-electric.com

# *wipos UPS 20-960*

Uninterruptable Power Supply

## **USER MANUAL**

Doc.-No. BA001052

Updated: 11/2018 (Rev. A)

**COPYRIGHT** This document is copyright-protected. The rights derived from this copyright are reserved for Wieland Electric GmbH. Reproduction of this document or parts of this document is only permissible within the limits of the statutory provision of the Copyright Act. Any modification or abridgment of the document is prohibited without the express written agreement of Wieland Electric GmbH.

Any other product or trade names listed in these operating instructions are the trademarks or registered trademarks of the respective owners.

**NOTE** Every effort has been made to ensure that the information contained in this document was complete and accurate at the time of publishing. Nevertheless, the authors retain the right to modify the information. This customer document describes all the hardware units and functions known at the present time. Descriptions may be included for units which are not present at the customer site. The exact scope of delivery is described in the respective purchase contract.

**Conformity Information** For more information regarding CE marking and Declaration of Conformity (DoC), please contact your local Wieland Electric customer service organization.



**Technical support** Up-to-date information concerning the product is available from the following websites:  
<http://www.wieland-electric.com/>  
<http://eshop.wieland-electric.com/>

Technical support

Industrial Automation -Electronics  
Hotline:  
+49 951 / 93 24-995  
E-Mail:  
AT.TS@wieland-electric.com

**Address** Wieland Electric GmbH  
Brennerstraße 10-14  
96052 Bamberg

Phone: +49 (0) 9 51 93 24-0  
Fax: +49 (0) 9 51 93 24-198  
E-mail: [info@wieland-electric.com](mailto:info@wieland-electric.com)  
<http://eshop.wieland-electric.com>  
<http://www.wieland-electric.com>

## Table of Contents

1	About this manual .....	5
1.1	Target groups and qualification of personnel .....	5
1.2	Structure of the manual .....	5
1.3	Presentation of safety-relevant information .....	5
2	Product disposal instructions .....	7
3	Product description .....	8
3.1	Overview of the UPS module's front.....	8
4	Features and benefits .....	10
5	Function description .....	11
5.1	UPS mode .....	12
5.1.1	Backup (battery mode) .....	12
5.1.2	Battery health monitor.....	12
5.1.3	Battery charger .....	13
5.1.4	Coulomb counter .....	15
5.1.5	PC shutdown and automatic restart.....	15
5.1.6	Cold start .....	16
5.1.7	Blink output on backup .....	17
5.2	DC-DC mode .....	17
5.3	Current limit .....	18
5.3.1	Current limit in UPS mode.....	18
5.3.2	Current limit in DC-DC mode .....	18
5.4	Inhibit .....	18
5.5	Modbus .....	19
6	User interface .....	23
6.1	Status .....	24
6.2	Settings .....	24
6.3	Info menu .....	33
6.4	Logs.....	34
6.4.1	Info .....	34
6.4.2	Alarms .....	36
6.4.3	Events.....	40
6.5	Wizard (system configuration) .....	40

## Table of Figures

Figure 1 Front panel view .....	8
Figure 2 Terminal block 1 .....	8
Figure 3 Terminal block 2 .....	9
Figure 4 Simplified block diagram for UPS 20-960 .....	11
Figure 5 UPS connection example .....	12
Figure 6 Internal resistance measurement .....	13
Figure 7 Lead acid and Lithium charging algorithm.....	14
Figure 8 Nickel charging algorithm .....	14
Figure 9 Figure 7: Supercapacitors charging algorithm .....	14
Figure 10 Shutdown and restart chart .....	15
Figure 11 DC-DC connection example .....	17
Figure 12 UPS status screen .....	24
Figure 13 DC-DC status screen .....	24
Figure 14 Alarm screen .....	24
Figure 15 Log Screen .....	34

# 1 About this manual

Please read this section carefully before you use this manual and the *wipos* UPS from Wieland. Here you will find all the information required for commissioning and operation.

## 1.1 Target groups and qualification of personnel

Commissioning and installation of components for such types of installations must be considered.

Therefore, the system manual is targeted at the following:

- Those who can verify that they have the corresponding training and already have corresponding basic knowledge
- System integrators
- Electricians

## 1.2 Structure of the manual

As a guidance the overall table of contents is available in the manual at the beginning.

## 1.3 Presentation of safety-relevant information

Information that warns of personal injury or property damage are emphasized by safety instructions. Please read this information carefully.

This operating manual uses various safety notices that are assigned according to the severity of a potential hazard:

### **Danger!**

**Immediate or likely danger. Personal injury or death is possible.**



### **Warning!**

Possible danger. Not heeding this warning can lead to minor injuries.



### **Attention!**

Damages to property is likely if these warnings are not heeded.



### **NOTE:**

Supplementary information and useful tips, indirectly related to the safety of personnel or property.

NOTE

"Danger" or "Warning" are strictly used for cases which present a risk to life or limb. Damage to property only falls into these categories if there is also a risk of personal injury that corresponds to these levels.

Please, observe the following instructions:

**NOTE:**

Personnel which installs, programs, operates or maintains this device must have read and understood these instructions.

NOTE

**Warning!**

The personnel must be thoroughly familiar with all warnings, notes and procedures described in these operating instructions.

Where necessary, safety precautions and safety devices must comply with the applicable regulations.

Damaged products must neither be installed nor put into operation. In case of a defect, please return the device to Wieland Electric.

The unit must not be opened.

Do not insert any objects into the unit!

Keep the unit away from fire and water



WARNING

**Attention!**

Ensure appropriate installation before start of operation.

Do not cover any air ventilation holes.

Use the device only as intended.



ATTENTION

## 2 Product disposal instructions

The WEEE (Waste Electrical and Electronic Equipment) directive has been introduced to ensure that electrical/electronic products are recycled using the best available recovery techniques to minimize the impact on the environment.

This product contains high quality materials and components which can be recycled. At the end of its life this product **MUST NOT** be mixed with other commercial waste for disposal. Check the terms and conditions of your supplier for disposal information.

## 3 Product description

### NOTE:

Use latest device Documentation, Software and Firmware to ensure reliable operation of the system (downloadable from [www.wieland-electric.com](http://www.wieland-electric.com)).

The UPS 20-960 is a microprocessor controlled unit that can perform two functions:

- UPS rated 960 W / 20 A usable in any system rated 12 ... 48 V DC
- DC-DC converter (non-isolated) rated 960 W / 20 A usable in any combination of IN/OUT voltages 12 ... 48 V DC

For the UPS function, it may use a battery of 12 V, independently of the operating load voltage. For any supply voltages (12 ... 48 V DC) it may use also multiple battery configuration (10 ... 58 V DC). The UPS module monitors the voltage coming from a DC power supply and in case of power failure a backup battery is supplying the energy to the load. In normal condition the battery is kept charged by an integrated battery charger supporting various battery chemistries.

As a DC-DC converter (no battery present) the input must be connected to the battery connector. The input voltage is converted to any output voltage as per the set-up.

### 3.1 Overview of the UPS module's front




Figure 1 Front panel view




Figure 2 Terminal block 1

1. **Alarm LED indicator:** ON when the unit is in backup. Blinks at 1 Hz rate in case of error.
2. **Modbus over USB:** Used to connect a PC with user software or custom application for remote monitoring and controlling. Firmware update is also possible through USB connection.
3. **Temperature sensor:** Optional temperature sensor (*wipos* UPS 20 Sensor) to measure the battery temperature for protection and temperature compensated charge method.
4. Terminal block 1
5. Terminal block 2
6. **Display area:** provides information regarding the device status.
7. **Control keys:** 4 push buttons are provided to navigate through the menus and to select the various functions.
8. **Relays dry contacts:** 2 relays (signal contacts) are present for remote monitoring. See no. 26 in section 6.2 for more details.
9. **Modbus over RS485:** Used to connect a PC with user software or custom application for remote monitoring and controlling. Firmware update is also possible through RS485 connection.
10. **Inhibit input:** A voltage between 5 V DC and 30 V DC applied to this input activates the inhibit function. See section 5.4 for more details.




Figure 3 Terminal block 2

11. **Auxiliary output supply:** Maximum 5 A supply from the battery (unregulated).
12. **Input connection:** 2 connectors are provided for input connection. This must be connected to a power supply rated 12 ... 48 V DC.
13. **Output connection:** 2 connectors are provided for output connection. It must be connected to the load to be backed up.
14. **Battery / DC-DC input connection:** 2 connectors are provided for battery connection. This must be connected to the battery in UPS mode or to the power supply in DC-DC mode. Although the unit is protected the correct polarity must be respected

## 4 Features and benefits

The main features are:

- Integrated battery charger for 12 ... 48 V DC multi-chemistries batteries with a charging current up to 20 A
- Can be operated with SUPERCAP capacitors instead of batteries
- 20 A or 960 W rated load
- Automatic sensing of input voltage, load current and battery current
- Battery protection against reverse polarity connection and overcurrent
- Battery health monitoring system: measuring battery resistance, battery temperature, charge/discharge cycles and Coulomb counter
- User settable maximum backup time
- Remote inhibit input
- Connection for a battery thermal sensor (optional)
- Modbus over USB and RS485 interfaces for control and monitoring
- Auxiliary output from the battery voltage (max. 5 A), protected against overcurrent/short circuit
- Suitable for energy management applications
- Suitable for user software

Embedded user interface:

- 4 keys and 1 color graphic LCD display
- Allows online device configuration
- Displays the UPS module's status, logs and alarms
- 2 dry contacts for programmable status signals

PC user software used for:

- Connection through Modbus
- Remote monitoring and configuration
- Firmware upgrade
- Same functionalities of the embedded user interface with the ease of the PC benefits

## 5 Function description

The UPS 20-960 is a high performance digitally controller DC-UPS that can be used in any DC system with a rated voltage between 12 V and 48 V and up to 20 A.

At the core of the device a bidirectional DC/DC buck-boost converter (see Figure 4) acts as a battery charger when the input supply is present. In case of a power outage (backup) the converter keeps the output voltage regulated draining power from the battery. The converter is digitally controlled.




Figure 4 Simplified block diagram for UPS 20-960

## 5.1 UPS mode




Figure 5 UPS connection example

In UPS mode the UPS module protects a load from unwanted power interruption in case of mains failure. An example of UPS connection is given in Figure 5.

When the input is present, the UPS module acts as a bypass, connecting the input to the output via the input switch. Meanwhile, if required, the battery is charged. During bypass there is no voltage conversion, therefore the output supply voltage is equal to the input voltage.

In case of power outage, the UPS module takes energy from the battery to keep the output regulated at nominal output voltage. See no. 20 in section 6.2 for more details.

### 5.1.1 Backup (battery mode)

The system is in backup mode if the supply for the output is sourced from the battery (input supply missing). During backup the battery is monitored continuously to prevent over discharge.

A **programmable backup timer** is also implemented in order to fix a maximum backup time during power outages. This allows preserving the battery life and shortening the recharge time, avoiding discharging the battery when not needed. See no. 24 in section 6.2 for more details.

During backup the internal Coulomb counter is used to give an estimation of the residual charge of the battery.

Backup starts when the output voltage is lower than 90% of the nominal output voltage. See no. 20 in section 6.2 for more details.

### 5.1.2 Battery health monitor

The battery health monitor is composed of:

- Internal resistance measurement: The resistance is periodically measured. The internal resistance is a good indicator of the battery health status; a sudden increase of the internal resistance indicates a potential problem on the battery or on the battery wiring.
- Temperature measurement: The battery temperature is monitored through an optional temperature sensor (*wipos* UPS 20 Sensor). The battery charger takes into account the battery temperature and provides a temperature compensated charging voltage. In case of over or under temperature the system disconnects the battery to prevent damage.
- Coulomb counter: Estimates the remaining battery capacity and consequently the available backup time.
- Deep discharge protection: It protects against the deep discharge of the battery which can lead to its irreversible damage.

The battery internal resistance ( $R_i$ ) is measured by draining a defined AC current through an active load (AL) from the battery and measuring the AC voltage drop across the load terminals. The principle is represented in Figure 6.




Figure 6 Internal resistance measurement

The measured resistance is the sum of the *battery internal resistance*, the *cables resistance* and the *connectors resistance*, therefore cabling problem such as loose connectors are also detected with  $R_i$  measurement.

When high capacity batteries and/or small and long cables are used,  $R_{cables} + R_{con}$  may be  $> R_i$ .

### 5.1.3 Battery charger

The battery charger supports batteries such as Lead-Acid, Nickel, Lithium and Supercapacitors. The charging algorithm for each chemistry is given below.

The battery charger automatically reduces the current to avoid exceeding the maximum input current in case of high current load. See no. 21 in section 6.2 for more details.

The user must set the following parameters to allow the charger to perform correctly:

- Battery type (see no. 5 in section 6.2)
- Battery charge voltage (see no. 6 in section 6.2)
- Battery charge current (see no. 7 in section 6.2)
- Battery float voltage (see no. 8 in section 6.2)

The battery charge terminates in case at least one of the following conditions are satisfied:

- **Low current:** The measured battery charge current is lower than 10% of the battery charge current while the measured voltage is at least 98% of the battery charge voltage.
- **Timer:** the charge is terminated after the battery has been charged for a predetermined amount of time. The value is automatically calculated by the device.

For Nickel batteries only, the following conditions are also checked:

- **Temperature Cutoff (TCO):** The battery temperature is higher than the "Battery maximal temperature" minus 3 °C for more than one minute. See no. 14 in section 6.2 for more details. For example, if the maximal battery temperature is set to 60 °C, the charge terminates in case the temperature is higher than 57 °C.
- **Rate of Temperature Increase ( $\Delta T/dt$ ):** The battery temperature is rising at a rate equal or superior to 1 °C/min. To avoid unattended end of charge do not place the system on an ambient with rapid changes of temperature (for example exposed to direct sunlight).

The charger voltage is independent on the input voltage (power supply), and is user settable.  
 Lead acid and lithium batteries share the same 3 stages charging algorithm as shown on Figure 7.




Figure 7 Lead acid and Lithium charging algorithm

For nickel batteries, during maintenance, the UPS module gives pulses of 3 s every 30 s with a maximum current of 1/10 of the battery charge current and maximum voltage equal to the battery charge voltage.




Figure 8 Nickel charging algorithm

For Supercapacitor after the constant current phase the algorithm goes directly to maintenance keeping the voltage at battery charge voltage.




Figure 9 Figure 7: Supercapacitors charging algorithm

**Warning!**

In order to avoid potentially hazardous situations including fire hazard, safety recommendations must be followed. Only authorized staff can install the unit.

**Warning!**

For Lithium cells the balancing and protection circuit must be included in the battery pack.

**Warning!**

For Nickel batteries the use of the external temperature sensor is mandatory. The sensor must be placed in contact with the battery.

**5.1.4 Coulomb counter**

The UPS module measures the current flowing from / to the battery to keep track of the capacity available on the battery. The capacity is measured in Ampere Hour [Ah]. The value shown is based on the following assumptions:

- The value shown is just informative and does not represent the real state of charge of the battery in some circumstances, for example if the battery is damaged.
- When the battery is connected for the first time or the system starts from OFF, the system assumes the battery is fully discharged and start with 0 Ah counter.
- Once the battery is fully charged the system sets the counter to the nominal capacity specified by the user. See no. 12 in section 6.2 for more details.

**5.1.5 PC shutdown and automatic restart**

**PC shutdown:** In case the UPS module is used to supply a PC it is possible to automatically shut down the PC after an adjustable time of backup. For this the PC must run the user software and must be connected through Modbus. Optionally the user software can call a task on the PC before shutting down, for example to backup some sensitive data.

**Automatic restart:** UPS module is able to automatically restart a PC which was powered OFF by mistake, for example in case of the Operating System (OS) crash. The user may adjust an output current threshold and a timer used for detecting the PC OFF status. In order to restart the PC, the UPS module toggles the output OFF and then ON again. User must enable in the PC BIOS the automatic start in case of supply ON.

The diagram below shows the UPS module's behavior when Shutdown and Automatic restart is enabled.




Figure 10 Shutdown and restart chart

Parameter	Name	Description
E1	<i>Backup</i>	Power failure on the line happens. System enters backup mode.
E2	<i>Automatic PC shutdown</i>	The user software sends a shutdown command to the PC. Optionally: a task is called before shutdown.
E3	<i>Unexpected PC shutdown</i>	The PC shutdowns in an unexpected way, for example caused by OS crash.
E4	<i>PC restart</i>	The UPS module detects the PC being OFF because the output current was lower than I <sub>off</sub> current threshold for T4 time. As a consequence, the UPS module generates an ON->OFF->ON cycle on its output.
T1	<i>PC shutdown delay</i>	User settable (see no. 36 in section 6.2). Time between start of backup and start of PC shutdown procedure.
T2	<i>PC shutdown time</i>	User settable (see no. 37 in section 6.2). Time between start of shutdown procedure and output voltage OFF. This time must be set longer than the maximum time the PC takes to complete the shutdown.
T3	<i>PC restart minimum OFF time</i>	User settable (see no. 38 in section 6.2). T3 is the delay used between the return of the input voltage and the activation of the output. The same time is used by the automatic restart function as power OFF time to restart the PC. The value must be big enough for the PC to detect the supply ON->OFF->ON cycle to restart.
T4	<i>PC OFF detection timer</i>	User settable (see no. 40 in section 6.2). Minimum time at which the output current must be below the I <sub>off</sub> current threshold to trigger the automatic PC restart (PC supply ON->OFF->ON cycle).
I <sub>off</sub>	<i>PC OFF detection current threshold</i>	User settable (see no. 39 in section 6.2). Current threshold used to detect PC OFF status. This value must be lower than the minimum PC current consumption when this is ON.

Table 1 Shutdown and restart

The parameters are settable through the UPS module user interface or using the user software. The checkbox "Run on startup" must be checked in the user software when PC shutdown function is used. To inhibit the software from calling the shutdown command, the user can select the "Inhibit shutdown" check box.

### 5.1.6 Cold start

The cold start is a procedure that allows turning ON the UPS without the input power. This procedure is used to turn ON the UPS to operate during a power interruption. This practice is also a method to see if the battery connected to the UPS module is functional.

In cold start the UPS module will remain ON for at least 60 seconds independently from the battery voltage (even when being under the deep discharge threshold), the inhibit input and the backup timer.

After the first 60 seconds the device stays ON until the battery is not deep discharged, the backup timer is not expired or the inhibit input is not active.

When cold started, the "Cold start" text is written beside the input icon on the status screen.

If the input supply returns during cold start, the device reverts to normal operation.

To cold start the device the user has the following options:

- **From front panel:** Press and hold simultaneously the  and  buttons until you see the welcome message on the screen.
- **Remotely through inhibit input:** When enabled on the user setting (see no. 32 in section 6.2), the device can be cold started toggling the inhibit status from true to false.

- **On battery connection:** When enabled on the user settings (see no. 33 in section 6.2), the device automatically cold starts when the battery, previously disconnected, is connected to the device.

### 5.1.7 Blink output on backup

When this option is enabled, during backup, the output voltage switches on/off periodically with the timing defined on "Blink output on backup Ton" and "Blink output on backup Toff" (see no. 42 and no. 43 in section 6.2). This function may be used on illumination application where is necessary to inform the person in the building that the lighting is running on batteries.

## 5.2 DC-DC mode

The UPS module can be used as a high performance DC-DC converter. An example of DC-DC connection is given on Figure 11.

Any voltage between 10 V to 55 V can be converted to any voltage between 10 V to 55 V (step-up and step-down operation) with up to 20 A input or output current.

Input and output are protected against over current with user settable limits. See section 5.3 for more details.

When used as a DC-DC converter, the input supply must be connected to the battery connector as shown on Figure 11.




Figure 11 DC-DC connection example

## 5.3 Current limit

The UPS module has the ability to limit the current flowing through its input, output and battery terminals to a user settable threshold.

### 5.3.1 Current limit in UPS mode

In UPS mode the UPS module provides 4 different settings for the current limit:

- **Maximum input current** (see no. 21 in section 6.2), default 20 A: it is used to limit the input current at a specified threshold. For example, if the DC power supply is rated less than 20 A, the threshold can be lowered to avoid too high current drain from the power supply. When the input current limit is reached, the battery charging current is limited. If the input current cannot be kept below the threshold due to excessive loading, an input overcurrent alarm is triggered. When the input current is approaching the threshold, the measured input current is displayed with red fonts on the LCD.
- **Maximum output current** (see no. 22 in section 6.2), default 20 A: it is used to limit the maximum current delivered to the load. When the threshold is reached due to excessive loading, an output overcurrent alarm is triggered. When the output current is approaching the threshold, the measured output current is displayed with red fonts on the LCD.
- **Battery maximum charge current** (see no. 7 in section 6.2), default 0.5 A (maximum settable 20 A): it is used to limit the maximum charge current supplied to the battery. This threshold will be automatically reduced in such manner that the maximum input current limit (see no. 21 in section 6.2) is distributed to the load with priority towards the charging.  
For example, if the maximum input current limit is 20 A and the load needs 10 A while the maximum charge current is set at 12 A, the controller will limit the charging current automatically to 10 A until the load will need <10 A.
- **Battery maximum discharge current** (see no. 11 in section 6.2), default 20 A: it is used to limit the maximum discharge current delivered from the battery during the backup function. When the threshold is reached due to excessive loading, a battery overcurrent alarm is triggered and the output voltage starts to decrease. When the battery discharge current is approaching the threshold, the measured battery current is displayed with red fonts on the LCD.

### 5.3.2 Current limit in DC-DC mode

In DC-DC mode the UPS module provides 2 different settings for the current limit:

- **Maximum input current** (see no. 21 in section 6.2), default 20 A: it is used to limit the input current at a specified threshold. For example, if the DC power supply is rated less than 20 A, the threshold can be lowered to avoid too high current drain from the power supply. When the input current limit is reached due to excessive loading, an input overcurrent alarm is triggered. When the input current is approaching the threshold, the measured input current is displayed with red fonts on the LCD.
- **Maximum output current** (see no. 22 in section 6.2), default 20 A: it is used to limit the maximum current delivered to the load. When the threshold is reached due to excessive loading, an output overcurrent alarm is triggered and the output voltage starts to decrease. When the output current is approaching the threshold, the measured output current is displayed with red fonts on the LCD.

## 5.4 Inhibit

An **opto-isolated input** allows the inhibition of the backup function in UPS mode or switching off the output on DC-DC mode. The polarity of the input can be defined using the "Inhibit polarity" field. See no. 28 in section 6.2 for more details.

## 5.5 Modbus

The UPS module communicates through Modbus/RTU as specified on "MODBUS over Serial Line" and "MODBUS APPLICATION PROTOCOL SPECIFICATION" documents available on <http://www.modbus.org/>.

Table 2 contains the field types and Table 3 the mapped fields. For types bigger than 16 bit, access all registers in one transaction (multiple register read or write) to ensure atomic operation.

Type	Modbus function codes		Description		
	Read	Write			
BIT	1,2	5,15	Single bit with value 0 or 1		
SINT16	3,4	6,16	Signed 16 bit value (2's complement)		
UINT16	3,4	6,16	Unsigned 16 bit value		
SINT32	3	16	Signed 32 bit value (2's complement) Composed of 2 consecutive registers in big-endian order.		
UINT32	3	16	Unsigned 32-bit value. Composed of 2 consecutive registers in big-endian order.		
DATE	3	16	Time and date field. Composed of 4 Modbus registers as follows:		
			<b>Address offset</b>	<b>Byte</b>	<b>Description</b>
			0	MSB	Reserved, set to 0
				LSB	Year-2000
			1	MSB	Month (1=January)
				LSB	Day of the month
			2	MSB	Hour of the day (24h format)
				LSB	Minutes
3	MSB	Milliseconds			
	LSB				

Table 2 Modbus types

Address	Type	R/W	Unit	Min.	Max.	Description
Common						
0x0010	DATE	R/W			R/W	Real time clock
Settings (see section 6.2)						
0x1000	UINT16	R/W	1	1	247	Modbus address
0x1001	UINT16	R/W	1	1	5	Modbus baud rate 1: 9600 baud 2: 19200 baud 3: 38400 baud 4: 57600 baud 5: 115200 baud
0x1002	UINT16	R/W	1	1	3	Modbus parity 1: None 2: Even 3: Odd
0x1003	UINT16	R/W	1	1	2	Modbus stop bits
0x1010	UINT16	R/W	1	1	4	Battery type 1: Lead 2: Nickel 3: Lithium 4: Supercapacitor
0x1011	UINT16	R/W	0.1 V	10	58	Battery charge voltage

Address	Type	R/W	Unit	Min.	Max.	Description
0x1012	UINT16	R/W	0.1 A	0.5	20	Battery charge current
0x1013	UINT16	R/W	0.1 V	10	58	Battery float voltage
0x1014	UINT16	R/W	0.1 V	5	58	Battery low voltage
0x1015	UINT16	R/W	0.1 V	5	58	Battery deep discharge voltage
0x1016	UINT16	R/W	0.1 A	5	21	Battery max. discharge current
0x1017	UINT16	R/W	0.1 Ah	1	200	Battery capacity - Supercap capacitance
0x1018	SINT16	R/W	1 °C	-40	60	Battery min. temperature
0x1019	SINT16	R/W	1 °C	-40	60	Battery max. temperature
0x101A	UINT16	R/W	1 kh	1	100	Battery lifetime
0x101B	UINT16	R/W	1	0	3	Ri alarm mode 0: Disabled 1: Fix 2: Automatic 3: Automatic done
0x101C	UINT16	R/W	0.1 m $\odot$	0	300	Ri nom
0x101D	UINT16	R/W	1%	50	300	Ri max. variation
0x1020	UINT16	R/W	1	1	2	Operating mode 1: UPS 2: DC-DC
0x1021	UINT16	R/W	0.1	10	58	Nominal output voltage
0x1022	UINT16	R/W	0.1	5	21	Max. input current
0x1023	UINT16	R/W	0.1	1	21	Max. output current
0x1024	UINT16	R/W	1	0	1	Max. Backup time enable 0: Disabled 1: Enabled
0x1025	UINT16	R/W	1 m	1	1440	Max. backup time.
0x1026	UINT16	R/W	1	0	1	Buzzer enable 0: Disabled 1: Enable
0x1027	UINT16	R/W	1	0	65535	Relay 1 configuration (see no. 27 in section 6.2)
0x1028	UINT16	R/W	1	0	65535	Relay 2 configuration (see no. 27 in section 6.2)
0x1029	UINT16	R/W	1	1	2	Inhibit polarity 1: Low 2: High
0x102A	UINT16	R/W	1	1	2	DC-DC output mode 1: Single 2: Parallel
0x102B	UINT16	R/W	1	0	1	Output enable 0: Disabled 1: Enabled
0x102C	UINT16	R/W	1	0	1	Aux enable 0: Disabled 1: Enabled
0x102D	UINT16	R/W	1	0	1	Cold start on inhibit toggle 0: Disabled 1: Enabled
0x102E	UINT16	R/W	1	0	1	Cold start on battery connection 0: Disabled 1: Enabled
0x1030	UINT16	R/W	1	0	1	PC shutdown enable

Address	Type	R/W	Unit	Min.	Max.	Description
						0: Disabled 1: Enabled
0x1031	UINT16	R/W	1	0	1	PC automatic restart enable. 0: Disabled 1: Enabled
0x1032	UINT16	R/W	1 s	1	3600	PC shutdown delay
0x1033	UINT16	R/W	1 s	1	600	PC shutdown time
0x1034	UINT16	R/W	1 s	1	60	PC restart minimum time
0x1035	UINT16	R/W	0.1 A	0	20	PC off detection current threshold
0x1036	UINT16	R/W	1 s	1	60	PC off detection timer
0x1040	UINT16	R/W	1	0	1	Blink output on backup enable 0: Disabled 1: Enabled
0x1041	UINT16	R/W	1 s	10	600	Blink output on backup Ton
0x1042	UINT16	R/W	0.1 s	0.1	60	Blink output on backup Toff
0x1043	UINT16	R/W	1	0	1	Output short circuit latch enable 0: Disabled 1: Enabled
0x1044	UINT16	R/W	0.1 V	3	58	Output short circuit detection voltage threshold
0x1045	UINT16	R/W	1	0	1	High inrush load enable 0: Disabled 1: Enabled
0x1100	DATE	R/W	1	0	1	Battery installation date
0x1104	UINT16	R/W	1	0	65535	Battery charge cycles
<b>Metering</b>						
0x2000	SINT16	R	0.1 V	0	60	Input voltage
0x2001	SINT16	R	0.1 A	0	40	Input current
0x2002	SINT16	R	0.1 V	0	60	Output voltage
0x2003	SINT16	R	0.1 A	0	40	Output current
0x2004	SINT16	R	0.1 V	0	60	Battery voltage
0x2005	SINT16	R	0.1 A	-25	25	Battery current
0x2006	SINT16	R	0.1 V	0	60	Auxiliary voltage
0x2007	SINT16	R	0.1 A	0	20	Auxiliary current
0x2008	SINT16	R	0.1 °C	-40	85	External temperature
0x2009	SINT16	R	0.1 m $\Omega$	0	3000	Battery internal resistance
0x200A	SINT16	R	0.1 %	0	100	Battery charge percent
0x200B	SINT16	R	0.1 Ah	0	10000	Battery charge capacity
0x2010	UINT16	R	1 cycle	0	65535	Boot cycles
0x2020	UINT32	R	1 h	0	500000	Operating time
0x2022	UINT32	R	1 h	0	500000	Battery operating time
<b>Commands</b>						
0x3000	BIT	W	1	0	1	Perform Ri measurement
0x3001	BIT	W	1	0	1	Shutdown
0x3002	BIT	W	1	0	1	Reset device
<b>State (see section 6.4)</b>						
0x4000	BIT	R	1	0	1	Battery charging
0x4001	BIT	R	1	0	1	Battery floating
0x4002	BIT	R	1	0	1	Battery discharging
0x4010	BIT	R	1	0	1	Battery disconnected

Address	Type	R/W	Unit	Min.	Max.	Description
0x4011	BIT	R	1	0	1	Battery Ri too high
0x4012	BIT	R	1	0	1	Battery undertemperature
0x4013	BIT	R	1	0	1	Battery overtemperature
0x4014	BIT	R	1	0	1	Battery lifetime elapsed
0x4015	BIT	R	1	0	1	Battery charge failure
0x4016	BIT	R	1	0	1	Battery SoC <25%
0x4017	BIT	R	1	0	1	Battery over discharge current
0x4018	BIT	R	1	0	1	Battery low
0x4019	BIT	R	1	0	1	Battery deep discharged
0x4020	BIT	R	1	0	1	USB powered
0x4021	BIT	R	1	0	1	Cold start
0x4022	BIT	R	1	0	1	PC shutdown
0x4023	BIT	R	1	0	1	PC power off
0x4024	BIT	R	1	0	1	External temperature sensor presence
0x4025	BIT	R	1	0	1	Inhibit
0x4026	BIT	R	1	0	1	Output disabled
0x4027	BIT	R	1	0	1	Auxiliary output disabled
0x4030	BIT	R	1	0	1	Backup
0x4031	BIT	R	1	0	1	Input undervoltage
0x4032	BIT	R	1	0	1	Input overvoltage
0x4033	BIT	R	1	0	1	Output undervoltage
0x4034	BIT	R	1	0	1	Output overvoltage
0x4035	BIT	R	1	0	1	Output overload
0x4036	BIT	R	1	0	1	Input overcurrent
0x4037	BIT	R	1	0	1	Auxiliary output overload
0x4038	BIT	R	1	0	1	External temperature sensor error
0x4039	BIT	R	1	0	1	Backup time left <25%
0x403A	BIT	R	1	0	1	Warning overtemperature
0x403B	BIT	R	1	0	1	Error overtemperature

Table 3 Modbus fields

## 6 User interface

<p><b>Power ON screen</b> This screen is shown at power ON. It shows the device name, serial number and firmware version.</p>	<p>The flowchart illustrates the user interface navigation. It starts with a Power ON screen showing device information. From there, users can navigate to STATUS, SETTINGS, INFO, LOGS, or WIZARD. STATUS shows power status (U=0.00V, I=0.00A, U=24.00V, I=7.77A, U=10.20V, I=0.00A, C=94%). SETTINGS includes Date, Time, MB address, MB baudrate, MB parity, and MB stop bits. INFO shows Op. time, Bat. op. time, FW version, FW subversion, Build date, and Build time. LOGS shows a circular buffer of events with timestamps and details like 'In under volt. 1' and '21.6V'. WIZARD shows a 'System Wizard' screen asking 'Do you want to continue?' with 'Exit' and 'Next' options. Navigation is indicated by arrows and menu symbols.</p>
<p><b>Status</b> This is the default view where the user can find the most relevant information about the device status. The system always falls back to this view after 60 s of inactivity (no key pressed).</p>	
<p><b>Settings</b> All the device settings are configurable from this menu. Use the UP/DOWN key to navigate through the parameters. Press the OK key to enter/exit the editing mode. In editing mode use the UP/DOWN key to change the highlighted value.</p>	
<p><b>Info</b> Device information such as firmware version, serial number and device name is visible from this menu.</p>	
<p><b>Logs</b> All the alarms and event are logged in a circular buffer and visible from this screen. Use the UP/DOWN key to navigate through the logs.</p>	
<p><b>Wizard</b> The wizard helps the user to configure the system through a series of screens.</p>	

Table 4 User interface layout

Symbol	Name	Function
	MENU key	Menu selection / navigation
	UP/DOWN keys	navigation and selection in menu and to values
	OK key	confirm selection

Table 5 User interface keys

## 6.1 Status

The status screen shows the measurement and statuses to ease the system diagnostic. The screen is divided in sections identified by the symbols shown in Table 6.

Symbol	Name	Description
	Input	The measured input voltage and current is shown in this section.
	Output	The measured output voltage and current is shown in this section.
	Battery	The battery voltage, current, temperature, resistance and charge are shown in this section. During charging and discharging the symbol background color changes to orange and the number of bars drawn inside reflects the charge status. During discharging and charging an arrow drawn beside the symbol reflects the direction of the current flowing through the battery, pointing towards the battery during charging. Battery section is not present in DC-DC mode.
	Auxiliary	The measured auxiliary output voltage and current is shown in this section.

Table 6 Symbols on screen

For each section the icon background color reflects its status, green on healthy state or red/orange otherwise.

Furthermore, in case of alarm a message appears on the screen after 60 s of inactivity (no key pressed).

	U=0.0V I=0.0A
	U=24.0V I=7.7A
	U=10.2V C=94%
	U=10.2V I=0.0A

Figure 12 UPS status screen

DC/DC mode	
	U=10.3V I=19.1A
	U=24.0V I=7.7A
	U=10.2V I=0.0A

Figure 13 DC-DC status screen

1/1 
Battery disconnected. Check battery and connection.
Bat U=0.0V

Figure 14 Alarm screen

## 6.2 Settings

The setting menu contains all the configurable parameters available to the user. Use the UP/DOWN key to navigate through the menu items. Press the OK key to enter and exit the editing mode, exiting the edit mode stores and activates the new configuration. While in editing mode use the UP/DOWN key to change the selected value. All settings are also accessible via Modbus at the specified address. All the battery related settings are ignored in DC-DC operating mode.

1 Modbus address		
The Modbus slave address for the device. The same address is used for USB and RS485 connection.		
Default Value	Range	Resolution
1	1 ... 247	1
Unit	LCD name	Modbus address
N/A	Modbus address	0x1000

2 Modbus baud rate		
The baud rate for Modbus over RS485 serial port.		
Default Value	Values (Modbus value)	
38400	9600 (1), 19200 (2), 38400 (3), 57600 (4), 115200 (5)	
Unit	LCD name	Modbus address
N/A	Modbus baudrate	0x1001

3 Modbus parity		
The parity for Modbus over RS485 serial port. Available values are None, Even, Odd.		
<b>Default Value</b> Even	<b>Values (Modbus value)</b> None (1), Even (2), Odd (3)	
<b>Unit</b> N/A	<b>LCD name</b> Modbus parity	<b>Modbus address</b> 0x1002

4 Modbus stop bits		
The parity for Modbus over RS485 serial port.		
<b>Default Value</b> 1	<b>Range</b> 1, 2	<b>Resolution</b> 1
<b>Unit</b> N/A	<b>LCD name</b> Modbus stop bits	<b>Modbus address</b> 0x1003

5 Battery type		
Defines the type of battery connected to the device. See section 5.1.3 for details about the different charging algorithms.		
<b>Default Value</b> Pb	<b>Values (Modbus value)</b> Lead (1), Nickel (2), Lithium (3), SuperCap (4)	
<b>Unit</b> N/A	<b>LCD name</b> Bat. type	<b>Modbus address</b> 0x1010

6 Battery charge voltage		
The maximum voltage applied to the battery while charging. See section 5.1.3 for details about the use of this parameter on the different charging algorithms.		
<b>Default Value</b> 10 V	<b>Range</b> 10 ... 58 V	<b>Resolution</b> 0.1 V
<b>Unit</b> Volts	<b>LCD name</b> Bat. charge U	<b>Modbus address</b> 0x1011

7 Battery charge current		
The maximum current sourced to the battery while charging. See section 5.1.3 for details about the use of this parameter on the different charging algorithms.		
<b>Default Value</b> 0.5 A	<b>Range</b> 0.5 ... 20 A	<b>Resolution</b> 0.1 A
<b>Unit</b> Amperes	<b>LCD name</b> Bat. charge I	<b>Modbus address</b> 0x1012

8 Battery float voltage		
The maximum voltage applied to the battery once it is fully charged. See section 5.1.3 for details about the use of this parameter on the different charging algorithms.		
<b>Default Value</b> 10 V	<b>Range</b> 10 ... 58 V	<b>Resolution</b> 0.1 V
<b>Unit</b> Volts	<b>LCD name</b> Bat. Float U	<b>Modbus address</b> 0x1013

<b>9 Battery low voltage</b>		
Threshold for "Battery low" alarm (see no. 9 in section 6.4.2).		
<b>Default Value</b> 5 V	<b>Range</b> 5 ... 58 V	<b>Resolution</b> 0.1 V
<b>Unit</b> Volts	<b>LCD name</b> Bat. low U	<b>Modbus address</b> 0x1014

<b>10 Battery deep discharge voltage</b>		
Threshold for the "Battery deep discharged" alarm (see no. 10 in section 6.4.2).		
<b>Default Value</b> 5 V	<b>Range</b> 5 ... 58 V	<b>Resolution</b> 0.1 V
<b>Unit</b> Volts	<b>LCD name</b> Bat. deep disch. U	<b>Modbus address</b> 0x1015

<b>11 Battery max. discharge current</b>		
During backup the UPS module limits the maximum discharge current to this value reducing the output voltage if necessary.		
<b>Default Value</b> 21 A	<b>Range</b> 5 ... 21 A	<b>Resolution</b> 0.1 A
<b>Unit</b> Amperes	<b>LCD name</b> Bat. max. disch. I	<b>Modbus address</b> 0x1016

<b>12 Battery capacity – Supercap capacitance</b>		
Nominal capacity (Ah) of the installed battery or capacitance (F) in case a Supercapacitor is installed. This parameter is used to calculate the battery State of Charge (SoC) during charge and discharge.		
<b>Default Value</b> 1 Ah or 1 F	<b>Range</b> 1 ... 200 Ah or F	<b>Resolution</b> 0.1 Ah or F
<b>Unit</b> Ampere hours or Farad	<b>LCD name</b> Bat. capacity	<b>Modbus address</b> 0x1017

<b>13 Battery min. temperature</b>		
Threshold for the "Battery undertemperature" alarm (see no. 3 in section 6.4.2).		
<b>Default Value</b> -40 °C	<b>Range</b> -40 ... 60 °C	<b>Resolution</b> 1 °C
<b>Unit</b> Degree Celsius	<b>LCD name</b> Bat. min. T	<b>Modbus address</b> 0x1018

<b>14 Battery max. temperature</b>		
Threshold for the "Battery over temperature" alarm (see no. 4 in section 6.4.2).		
<b>Default Value</b> 60 °C	<b>Range</b> -40 ... 60 °C	<b>Resolution</b> 1 °C
<b>Unit</b> Degree Celsius	<b>LCD name</b> Bat. max. T	<b>Modbus address</b> 0x1019

15 Battery lifetime		
Threshold for the "Battery lifetime elapsed" alarm (see no. 5 in section 6.4.2).		
<b>Default Value</b> 100 kh	<b>Range</b> 1 ... 100 kh	<b>Resolution</b> 1 kh
<b>Unit</b> Kilo hours	<b>LCD name</b> Bat. lifetime	<b>Modbus address</b> 0x101A

16 Ri alarm mode		
Mode of operation for the "Battery Ri too high" alarm (see no. 2 in section 6.4.2).		
<b>Default Value</b> Disabled	<b>Values (Modbus value)</b> Disabled (0), Fixed (1), Automatic (2), Auto. Done (3)	
<b>Unit</b> N/A	<b>LCD name</b> Ri mode	<b>Modbus address</b> 0x101B

17 Ri nom.		
Used for the threshold calculation of the "Battery Ri too high" alarm (see no. 2 in section 6.4.2).		
<b>Default Value</b> 1 m $\odot$	<b>Range</b> 1 ... 300 m $\odot$	<b>Resolution</b> 0.1 m $\odot$
<b>Unit</b> Milli Ohm	<b>LCD name</b> Ri nominal	<b>Modbus address</b> 0x101C

18 Ri max. variation		
Used for the threshold calculation of the "Battery Ri too high" alarm (see no. 2 in section 6.4.2).		
<b>Default Value</b> 300%	<b>Range</b> 50 ... 300%	<b>Resolution</b> 1%
<b>Unit</b> Percent	<b>LCD name</b> Ri max. variation	<b>Modbus address</b> 0x101D

19 Operating mode		
Defines the UPS module's operating mode. See section 5.1 and 5.2 for details of each mode.		
<b>Default Value</b> UPS	<b>Values (Modbus value)</b> UPS (1), DC/DC (2)	
<b>Unit</b> N/A	<b>LCD name</b> Operating mode	<b>Modbus address</b> 0x1020

20 Nominal output voltage		
<b>UPS mode:</b> The UPS module enters backup mode when the output voltage drops below 90% of the nominal value. It is also the regulated output voltage during backup.		
<b>DC-DC mode:</b> The UPS module corresponds to the regulated output voltage.		
<b>Default Value</b> 10 V	<b>Range</b> 10 ... 58 V	<b>Resolution</b> 0.1 V
<b>Unit</b> Volts	<b>LCD name</b> Output nominal U	<b>Modbus address</b> 0x1021

**21 Max. input current**

**UPS mode:** The UPS module limits the maximum input current to this value reducing the battery charging current if necessary.

**DC-DC mode:** The UPS module limits the maximum input current (in DC-DC mode the input is connected to the battery connection) to this value reducing the output voltage if necessary.

<b>Default Value</b> 20 A	<b>Range</b> 1 ... 21 A	<b>Resolution</b> 0.1 A
<b>Unit</b> Amperes	<b>LCD name</b> Max input I	<b>Modbus address</b> 0x1022

**22 Max. output current**

The UPS module limits the maximum output current to this value reducing the output voltage if necessary.

<b>Default Value</b> 20 A	<b>Range</b> 5 ... 21 A	<b>Resolution</b> 0.1 A
<b>Unit</b> Amperes	<b>LCD name</b> Max output I	<b>Modbus address</b> 0x1023

**23 Max. Backup time enable**

If enabled, the UPS module shuts down if the backup last more than the "Max. backup time" value (see no. 24 in section 6.2).

<b>Default Value</b> Disabled	<b>Values (Modbus value)</b> Disabled (0), Enabled (1)	
<b>Unit</b> N/A	<b>LCD name</b> Backup time enable	<b>Modbus address</b> 0x1024

**24 Max. backup time**

If "Max. Backup time enable" field is enabled, the UPS module shuts down if the backup last more than the specified amount of time.

<b>Default Value</b> 1440 min	<b>Range</b> 1 ... 1440 min	<b>Resolution</b> 1 min
<b>Unit</b> Minutes	<b>LCD name</b> Back. time max	<b>Modbus address</b> 0x1025

**25 Buzzer enable**

Enable/Disable buzzer sound in case of alarm.

<b>Default Value</b> Disabled	<b>Values (Modbus value)</b> Disabled (0), Enabled (1)	
<b>Unit</b> N/A	<b>LCD name</b> Buzzer enable	<b>Modbus address</b> 0x1026

26 Relay 1 configuration		
<b>Default Value</b> Normally open, Bat. life time, Bat. Ri too high, Bat. Charge failure	<b>Flags (bit)</b> Normally open (0), Backup (1), Soc <25% (2), Bat. life time (3), Bat. Ri too high (4), Bat. Low (5), Bat. Disconnected (6), Bat. charge failure (7), Backup left <25% (8)	
<b>Unit</b> N/A	<b>LCD name</b> Relay 1	<b>Modbus address</b> 0x1027
This field defines the behavior of relay 1 as follows:		
<b>Normally open</b>	<b>1 or more enabled state active?</b>	<b>Relay contact status</b>
True	No	Open
True	Yes	Closed
False	No	Closed
False	Yes	Open

27 Relay 2 configuration		
This field defines the behavior of relay 2 (see "Relay 1 configuration", no. 26 in section 6.2).		
<b>Default Value</b> Normally open, Backup	<b>Flags (bit)</b> Normally open (0), Backup (1), Soc < 25% (2), Bat. life time (3), Bat. Ri too high (4), Bat. Low (5), Bat. Disconnected (6), Bat. charge failure (7), Backup left < 25% (8)	
<b>Unit</b> N/A	<b>LCD name</b> Relay 2	<b>Modbus address</b> 0x1028

28 Inhibit polarity		
Selects the active polarity of the inhibit input. See section 5.4 for more information about the inhibit function.		
<b>Default Value</b> High	<b>Values (Modbus value)</b> Low (1), High (2)	
<b>Unit</b> N/A	<b>LCD name</b> Inhibit polarity	<b>Modbus address</b> 0x1029

29 DC-DC output mode		
Select parallel mode in case the UPS module is configure as DC-DC with output connected in parallel with another unit.		
<b>Default Value</b> Single	<b>Values (Modbus value)</b> Single (1), Parallel (2)	
<b>Unit</b> N/A	<b>LCD name</b> DC/DC out mode	<b>Modbus address</b> 0x102A

30 Output enable		
Enable/Disable output.		
<b>Default Value</b> Enabled	<b>Values (Modbus value)</b> Disabled (0), Enabled (1)	
<b>Unit</b> N/A	<b>LCD name</b> Output enable	<b>Modbus address</b> 0x102B

<b>31 Aux enable</b>		
Enable/Disable auxiliary output.		
<b>Default Value</b> Enabled	<b>Values (Modbus value)</b> Disabled (0), Enabled (1)	
<b>Unit</b> N/A	<b>LCD name</b> Aux enable	<b>Modbus address</b> 0x102C

<b>32 Cold start on inhibit toggle</b>		
Enable/Disable the cold start on inhibit toggle. See section 5.1.6 for more details.		
<b>Default Value</b> Disabled	<b>Values (Modbus value)</b> Disabled (0), Enabled (1)	
<b>Unit</b> N/A	<b>LCD name</b> CS on inhibit	<b>Modbus address</b> 0x102D

<b>33 Cold start on battery connection</b>		
Enable/Disable the cold start on battery connection. See section 5.1.6 for more details.		
<b>Default Value</b> Disabled	<b>Values (Modbus value)</b> Disabled (0), Enabled (1)	
<b>Unit</b> N/A	<b>LCD name</b> CS on battery	<b>Modbus address</b> 0x102E

<b>34 PC shutdown enable</b>		
See section 5.1.5 for more details.		
<b>Default Value</b> Disabled	<b>Values (Modbus value)</b> Disabled (0), Enabled (1)	
<b>Unit</b> N/A	<b>LCD name</b> PC shutdown enable	<b>Modbus address</b> 0x1030

<b>35 PC automatic restart enable</b>		
See section 5.1.5 for more details.		
<b>Default Value</b> Disabled	<b>Values (Modbus value)</b> Disabled (0), Enabled (1)	
<b>Unit</b> N/A	<b>LCD name</b> PC restart enable	<b>Modbus address</b> 0x1031

<b>36 PC shutdown delay</b>		
See section 5.1.5 for more details.		
<b>Default Value</b> 3600 s	<b>Range</b> 1 ... 3600 s	<b>Resolution</b> 1 s
<b>Unit</b> Seconds	<b>LCD name</b> PC shutdown delay	<b>Modbus address</b> 0x1032

<b>37 PC shutdown time</b>		
See section 5.1.5 for more details.		
<b>Default Value</b> 600 s	<b>Range</b> 1 ... 600 s	<b>Resolution</b> 1 s
<b>Unit</b> Seconds	<b>LCD name</b> PC shutdown time	<b>Modbus address</b> 0x1033

<b>38 PC restart minimum time</b>		
See section 5.1.5 for more details.		
<b>Default Value</b> 1 s	<b>Range</b> 1 ... 60 s	<b>Resolution</b> 1 s
<b>Unit</b> Seconds	<b>LCD name</b> PC restart time	<b>Modbus address</b> 0x1034

<b>39 PC off detection current threshold</b>		
See section 5.1.5 for more details.		
<b>Default Value</b> 0 A	<b>Range</b> 0 ... 20 A	<b>Resolution</b> 0.1 A
<b>Unit</b> Amperes	<b>LCD name</b> PC OFF I	<b>Modbus address</b> 0x1035

<b>40 PC off detection timer</b>		
See section 5.1.5 for more details.		
<b>Default Value</b> 1 s	<b>Range</b> 1 ... 60 s	<b>Resolution</b> 1 s
<b>Unit</b> Seconds	<b>LCD name</b> PC OFF time	<b>Modbus address</b> 0x1036

<b>41 Blink output on backup enable</b>		
See section 5.1.7 for more details.		
<b>Default Value</b> Disabled	<b>Values</b> Disabled (0), Enabled (1)	
<b>Unit</b> N/A	<b>LCD name</b> Blink out enable	<b>Modbus address</b> 0x1040

<b>42 Blink output on backup Ton</b>		
See section 5.1.7 for more details.		
<b>Default Value</b> 10 s	<b>Range</b> 10 ... 600 s	<b>Resolution</b> 1 s
<b>Unit</b> Seconds	<b>LCD name</b> Blink out Ton	<b>Modbus address</b> 0x1041

**43 Blink output on backup Toff**

See section 5.1.7 for more details.

<b>Default Value</b> 0.2 s	<b>Range</b> 0.1 ... 60 s	<b>Resolution</b> 0.1 s
<b>Unit</b> Seconds	<b>LCD name</b> Blink out Toff	<b>Modbus address</b> 0x1042

**44 Output short circuit latch enable**

When enable the device disables the output when a short circuit is detected on the output. To restart the output, the operator must press the OK button on the front panel.

<b>Default Value</b> Disabled	<b>Values</b> Disabled (0), Enabled (1)	
<b>Unit</b> Seconds	<b>LCD name</b> Out SC latch enable	<b>Modbus address</b> 0x1043

**45 Output short circuit detection voltage threshold**

See section 5.1.7 for more details.

<b>Default Value</b> 3 V	<b>Range</b> 3 ... 58 V	<b>Resolution</b> 0.1 V
<b>Unit</b> Volts	<b>LCD name</b> Out SC detection th.	<b>Modbus address</b> 0x1044

**46 High inrush load enable**

When enabled and the output is switched on, the unit sends a higher current pulse to withstand loads with a high start-up inrush current.

<b>Default Value</b> Disabled	<b>Values</b> Disabled (0), Enabled (1)	
<b>Unit</b> N/A	<b>LCD name</b> High inrush enable	<b>Modbus address</b> 0x1045

**47 Battery installation date**

This field is used to compute the battery lifetime. If the battery lifetime exceeds the "Battery lifetime" value (see no. 15 in section 6.2), the "Battery lifetime elapsed" alarm activates (see no. 5 in section 6.4.2).

<b>Default Value</b> 1st January 2000	<b>Range</b> from 1st January 2000 to 31st December 2099	
<b>Unit</b> N/A	<b>LCD name</b> Bat. installation date	<b>Modbus address</b> 0x1100

**48 Battery charge cycles**

The value increments automatically at the end of a battery charge cycle.

<b>Default Value</b> 0	<b>Range</b> 0 ... 65535	<b>Resolution</b> 1
<b>Unit</b> Cycles	<b>LCD name</b> Bat. charge cycles	<b>Modbus address</b> 0x1104

## 6.3 Info menu

While in the info menu, use the UP/DOWN key to navigate through the menu items. The fields are also accessible via Modbus at the specified address. Modbus device identification fields are read using function 43/13 (0x2B/0x0E) at the specified object id.

<b>1 Firmware version</b>	
3.3 digit indicating the firmware major minor version	
<b>LCD name</b> FW version	<b>Modbus</b> Device Identification Object Id 0x02

<b>2 Firmware subversion</b>	
3 digit indicating the firmware subversion.	
<b>LCD name</b> FW subversion	<b>Modbus</b> Device Identification Object Id 0x80

<b>3 Build date</b>	
Firmware build date.	
<b>LCD name</b> Build date	<b>Modbus</b> Device Identification Object Id 0x82

<b>4 Build time</b>	
Firmware build time.	
<b>LCD name</b> Build time	<b>Modbus</b> Device Identification Object Id 0x83

<b>5 Serial number</b>	
Device serial number.	
<b>LCD name</b> S/N	<b>Modbus</b> Device Identification Object Id 0x81


<b>6 Boot cycles</b>		
Counter of power ON cycles.		
<b>Unit</b> Cycles	<b>LCD name</b> Boot cycles	<b>Modbus address</b> 0x2010

<b>7 Operating time</b>		
Counter for operating hours of the UPS module.		
<b>Unit</b> Hours	<b>LCD name</b> Operating time	<b>Modbus address</b> 0x2020

<b>8 Battery operating time</b>		
Hours elapsed since the "Battery installation date" (see no. 41 in section 6.2).		
<b>Unit</b> Hours	<b>LCD name</b> Bat. operating time	<b>Modbus address</b> 0x2022

## 6.4 Logs

Every event is logged in the device flash memory. From the log menu the user can view their history. Use the UP/DOWN keys to navigate between logs, 2 logs are visible simultaneously on the LCD.



1. **Time:** time at which the log occurred
2. **Date:** date at which the log occurred
3. **Name:** unique log name
4. **Primary value:** optional, see below for details
5. **Secondary value:** optional, see below for details

Figure 15 Log Screen

Logs are of 3 different kinds: **info**, **alarms** and **events**. All info and alarms have an associated Modbus field representing the current status (0 if inactive or 1 if active). For info and alarms a log is generated at each status transaction. In case of active alarm, the front LED and the buzzer turn ON.

### 6.4.1 Info

<b>1 Battery charging</b>	
Active when the battery is charging.	
<b>LCD name</b> Bat charging	<b>Modbus address</b> 0x4000
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Not used
<b>2 Battery floating</b>	
Active when the battery is fully charged.	
<b>LCD name</b> Bat floating	<b>Modbus address</b> 0x4001
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Not used
<b>3 Battery discharging</b>	
Active when the battery is discharging.	
<b>LCD name</b> Bat. discharging	<b>Modbus address</b> 0x4002
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Not used
<b>4 USB powered</b>	
The UPS module is powered by USB only.	
<b>LCD name</b> USB powered	<b>Modbus address</b> 0x4020
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Not used

5 Cold start	
The UPS module has powered ON through cold start (see section 5.1.6).	
<b>LCD name</b> Cold start	<b>Modbus address</b> 0x4021
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Not used

6 PC shutdown	
Command to shutdowns the PC (see section 5.1.5).	
<b>LCD name</b> PC shutdown	<b>Modbus address</b> 0x4022
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Not used

7 PC power off	
Command to power OFF the PC (see section 5.1.5), the UPS module's output switches OFF.	
<b>LCD name</b> PC power OFF	<b>Modbus address</b> 0x4023
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Not used

8 External temperature sensor presence	
Active if the optional external temperature sensor is connected.	
<b>LCD name</b> Ext. T sensor presence	<b>Modbus address</b> 0x4024
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Not used

9 Inhibit	
Active if the inhibit input signal is asserted (see section 5.4).	
<b>LCD name</b> Inhibit	<b>Modbus address</b> 0x4025
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Not used

10 Output disabled	
Active if the output is disabled in settings.	
<b>LCD name</b> Output disabled	<b>Modbus address</b> 0x4026
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Not used

<b>11 Auxiliary output disabled</b>	
Active if the auxiliary output is disabled in settings.	
<b>LCD name</b> Aux disabled	<b>Modbus address</b> 0x4027
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Not used

## 6.4.2 Alarms

<b>1 Battery disconnect</b>	
Active when no battery is detected by the UPS module.	
<b>LCD name</b> Bat. disconnected	<b>Modbus address</b> 0x4010
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Not used

<b>2 Battery Ri too high</b>	
Active when measured battery internal resistance exceeds the alarm threshold (see section 5.1.2).	
<b>LCD name</b> Bat. Ri too high	<b>Modbus address</b> 0x4011
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Status 0 → 1: Offending threshold Status 1 → 0: Max. measured value

<b>3 Battery undertemperature</b>	
Active when the battery measured temperature (using the optional external sensor) is under the threshold specified in "Battery min. temperature" field (see no. 13 in section 6.2). If active, the battery charged is disabled.	
<b>LCD name</b> Bat. under temperature	<b>Modbus address</b> 0x4012
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Status 0 → 1: Offending threshold Status 1 → 0: Min. measured value

<b>4 Battery overtemperature</b>	
Active when the battery measured temperature (using the optional external sensor) exceeds the threshold specified in "Battery max. temperature" field (see no. 14 in section 6.2). If active, the battery charged is disabled.	
<b>LCD name</b> Bat. over temperature	<b>Modbus address</b> 0x4013
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Status 0 → 1: Offending threshold Status 1 → 0: Max. measured value

<b>5 Battery lifetime elapsed</b>	
Active when the actual calculated battery lifetime exceeds the threshold specified in "Battery lifetime" field (see no. 15 in section 6.2).	
<b>LCD name</b> Bat. lifetime elapsed	<b>Modbus address</b> 0x4014
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Status 0 → 1: Offending threshold Status 1 → 0: Max. calculated value

<b>6 Battery charge failure</b>	
Active when the UPS module could not charge the battery correctly. When active, the battery charger is disabled. Disconnect the battery to reset the alarm.	
<b>LCD name</b> Bat. charge fail	<b>Modbus address</b> 0x4015
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Not used

<b>7 Battery SoC &lt;25%</b>	
Active when the battery State of Charge is under 25% of the nominal full charge capacity.	
<b>LCD name</b> Bat. SoC <25%	<b>Modbus address</b> 0x4016
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Not used

<b>8 Battery over discharge current</b>	
Active when the measured battery discharge current reaches the threshold specified in "Battery max. discharge current" field (see no. 11 in section 6.2).	
<b>LCD name</b> Bat. over discharge I	<b>Modbus address</b> 0x4017
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Status 0 → 1: Offending threshold Status 1 → 0: Max. measured value

<b>9 Battery low</b>	
Active when the measured battery voltage is under the threshold specified in "Battery low voltage" field (see no. 9 in section 6.2).	
<b>LCD name</b> Bat. low	<b>Modbus address</b> 0x4018
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Status 0 → 1: Offending threshold Status 1 → 0: Min. measured value

<b>10 Battery deep discharged</b>	
Active when the battery measured voltage is under the threshold specified in "Battery deep discharge voltage" field (see no. 10 in section 6.2).	
<b>LCD name</b> Bat. deep discharge	<b>Modbus address</b> 0x4019
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Status 0 → 1: Offending threshold Status 1 → 0: Min. measured value

<b>11 Backup</b>	
Active when the system is in backup (see section 5.1.1).	
<b>LCD name</b> Backup	<b>Modbus address</b> 0x4030
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Not used

<b>12 Input undervoltage</b>	
Active when the measured input voltage is under 90% of the "Nominal output voltage" field (see no. 20 in section 6.2).	
<b>LCD name</b> Input under voltage	<b>Modbus address</b> 0x4031
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Status 0 → 1: Offending threshold Status 1 → 0: Min. measured value

<b>13 Input overvoltage</b>	
Active when the measured input voltage exceeds 120% of the "Nominal output voltage" field (see no. 20 in section 6.2).	
<b>LCD name</b> Input over voltage	<b>Modbus address</b> 0x4032
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Status 0 → 1: Offending threshold Status 1 → 0: Max. measured value

<b>14 Output undervoltage</b>	
Active when the measured output voltage is under 90% of the "Nominal output voltage" field (see no. 20 in section 6.2).	
<b>LCD name</b> Output under voltage	<b>Modbus address</b> 0x4033
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Status 0 → 1: Offending threshold Status 1 → 0: Min. measured value

<b>15 Output overvoltage</b>	
Active when the measured output voltage exceeds 120% of the "Nominal output voltage" field (see no. 20 in section 6.2).	
<b>LCD name</b> Output over voltage	<b>Modbus address</b> 0x4034
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Status 0 → 1: Offending threshold Status 1 → 0: Max. measured value

<b>16 Output overload</b>	
Active when the measured output current reaches the threshold specified in "Max. output current" field (see no. 22 in section 6.2).	
<b>LCD name</b> Output overload	<b>Modbus address</b> 0x4035
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Not used

<b>17 Input overcurrent</b>	
Active when the measured input current reaches the threshold specified in "Max. input current" field (see no. 21 in section 6.2).	
<b>LCD name</b> Input over current	<b>Modbus address</b> 0x4036
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Not used

<b>18 Auxiliary output overload</b>	
Active when an excessive load is detected on the auxiliary output.	
<b>LCD name</b> Aux overload	<b>Modbus address</b> 0x4037
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Not used

<b>19 External temperature sensor error</b>	
Active when the external temperature sensor is not connected while its use is mandatory like in NiMH battery charging.	
<b>LCD name</b> Ext. T sensor error	<b>Modbus address</b> 0x4038
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Not used

<b>20 Backup time left &lt;25%</b>	
Active when the system is in backup and the maximal backup time is less than the "Max. backup time" field (see no. 24 in section 6.2).	
<b>LCD name</b> Backup time left <25%	<b>Modbus address</b> 0x4039
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Not used

<b>21 Warning overtemperature</b>	
Active when the internal temperature is high. If the temperature increases more, the device may switch OFF.	
<b>LCD name</b> Warn. over temperature	<b>Modbus address</b> 0x403A
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Not used

<b>22 Error overtemperature</b>	
Active when the internal temperature is too high. To prevent damage the device switches OFF.	
<b>LCD name</b> Error over temperature	<b>Modbus address</b> 0x403B
<b>Value 1</b> Inactive (0), Active (1)	<b>Value 2</b> Not used

### 6.4.3 Events

<b>1 Power ON event</b>	
Generated at every time when the UPS module is turned ON.	
<b>LCD name</b> Power ON	<b>Modbus address</b> 0xE000
<b>Value 1</b> Power ON count	<b>Value 2</b> Not used

<b>2 Shutdown event</b>	
Generated at every time when the UPS module is turned OFF.	
<b>LCD name</b> Shutdown	<b>Modbus address</b> 0xE001
<b>Value 1</b> Shutdown count	<b>Value 2</b> Shutdown reason: 1 - Deep discharge 2 - Max. backup time elapsed 3 - Shutdown command 4 - Reset command 5 - Inhibit signal

## 6.5 Wizard (system configuration)

The wizard assists the user during the UPS module configuration. It should be run once at commissioning.



Wieland Electric GmbH  
Brennerstraße 10–14  
D-96052 Bamberg  
Tel. 49 (0) 951 / 9324-0  
Fax 49 (0) 951 / 9324-128

Email [info@wieland-electric.com](mailto:info@wieland-electric.com)

<http://eshop.wieland-electric.com>

<http://www.wieland-electric.com>