Auxiliary elements and accessories

Auxiliary elements for S200, SN200, F200, DS200, DS203NC, DSE201M, SD200

| Signal contacts | Signal of a fault (overcurrent/short circuit) for MCB and RCBO's and earth fault for RCCB and RCBO. |
|---------------------------|---|
| Auxiliary contacts | Indication of the position of the devices contacts for MCB, RCCB, RCBO and switch disconnector. |
| Signal/auxiliary contacts | Selectable to indicate the position of the devices contacts (auxiliary contact) and signalling of a fault (overcurrent/short circuit for MCB's and RCBO's and earth fault for RCCB's and RCBO's). |
| Interface modules | For DSN201, SN201 and DS203NC. Allows other auxiliary contacts and accessories to be fitted. |



Signal/auxiliary contacts

| Description | Configuration | Suits | Order code |
|----------------------------------|---------------|---|-------------|
| Signal contact/auxiliary contact | 1CO | S200, F200, DS201, DS202C, DSE201M, SD200 | S2CSH6R |
| Signal contact/auxiliary contact | 1CO | S800 | S800AUX/ALT |

^{*} Accessories not suitable with DS201BS and SH200



Auxiliary contacts

| Description | Configuration | Suits | Order code |
|-------------------|---------------|---|------------|
| Auxiliary contact | 1CO | S200, F200, DS201, DS202C, SD200, DSE201M | S2CH6R |
| Auxiliary contact | 1NO/1NC | S200, F200, DS201, DS202C, SD200, DSE201M | S2CH11L |
| Auxiliary contact | 2NO | S200, F200, DS201, DS202C, SD200, DSE201M | S2CH20L |
| Auxiliary contact | 2NC | S200, F200, DS201, DS202C, SD200, DSE201M | S2CH02L |
| Auxiliary contact | 1CO | S800 | S800AUX |

 $^{^{\}star}$ Accessories not suitable with DS201BS and SH200



Interface module/auxiliary contact

| Description | Configuration | Suits | Order code |
|-------------------|---------------|------------------------|------------|
| Interface module/ | 1CO | SN201, DSN201, DS203NC | SN201-IH |
| auxiliary contact | | | |

Signalling contact

| Description | Configuration | Suits | Order code |
|----------------|---------------|--------------|------------|
| Signal contact | 1CO | SN201, DS201 | SN201S |

 $^{^{\}star}$ Accessories not suitable with DS201BS and SH200



Bottom fitting auxiliary contacts

Unique auxiliary contact that fits to the bottom of an MCB saving space on the DIN rail

| Description | Configuration | Suits | Order code |
|----------------------------------|---------------|---------------|------------|
| Bottom fitting auxiliary contact | 1NC | S200, DSE201M | S2CH01 |
| Bottom fitting auxiliary contact | 1NO | S200, DSE201M | S2CH10 |